

A11

# RIM BOARD

Fasten rim board to each floor Joist using one 8d nail or 10d box nail 1" from the top and bottom surface

